

TENANT FLOOR WARDEN PROCEDURES



1001 Pennsylvania Avenue NW

Washington, DC, 20004-2505

TABLE OF CONTENTS

TABLE OF CONTENTS..... 2

TENANT FLOOR WARDEN TEAM ORGANIZATIONAL CHART 3

PERSONNEL DESCRIPTIONS..... 3

 Tenant Floor Wardens3

 Deputy Tenant Floor Wardens.....3

 Stair Monitors.....4

 Floor Searchers4

 Assistance Monitors.....4

FIRE PROCEDURES 5

 Tenant Floor Wardens – Fire Procedures.....5

 Evacuation Drill Report7

 Deputy Tenant Floor Wardens – Evacuation Procedures8

 Stair Monitors – Evacuation Procedures.....9

 Floor Searchers – Evacuation Procedures10

 Assistance Monitors – Evacuation Procedures.....11

 Instructions to Operate Fire Extinguishers.....12

NATURAL DISASTER PROCEDURES..... 13

 Tenant Floor Wardens – Earthquake Procedures.....13

 Tenant Floor Wardens – Tornado Procedures.....15

HUMAN INDUCED / TECHNOLOGY FAILURE PROCEDURES..... 17

 Tenant Floor Wardens – Bomb Threat Procedures17

 Identifying a Possible Package Bomb18

 Tenant Floor Wardens – Suspicious Package Procedures.....19

 Tenant Floor Wardens – Shelter-In-Place Procedures20

 Tenant Floor Wardens – Power Failure Procedures.....21

 Tenant Floor Wardens – Personal Violence Procedures22

FIRST AID PROCEDURES 24

 Emergency First Aid.....24

PERSONS REQUIRING ASSISTANCE 27

FACILITY DESCRIPTION 31

 General Description of the Office Building31

 Fire Alarm System31

 Exit System.....31

 Communications32

 Emergency Power.....33

 Elevators.....33


 Fire Equipment.....33

NOTES 34

EVACUATION PLAN..... 36

TENANT FLOOR WARDEN TEAM ORGANIZATIONAL CHART

(During Emergency Condition)



PERSONNEL DESCRIPTIONS

Tenant Floor Wardens (TFW)

Tenant Floor Wardens are responsible for the supervision of the occupants in an orderly evacuation of their office spaces to the recommended assembly area, either within the building or outside, should an evacuation or relocation be ordered by the authorities or the Building Incident Commander. They are also responsible for communicating with the Building Incident Commander / Assembly Area Coordinator on the status of the office space, the disposition of persons requiring assistance to evacuate, and any missing occupants. Tenant Floor Wardens report directly to the Building Incident Commander or the Operations Section Chief (delayed response by the authorities). Should any of the members of the Tenant Floor Warden team (Deputy Tenant Floor Wardens, Stair Monitors, Floor Searchers, Assistance Monitors) be unable to fulfill their duties as outlined in this manual (e.g., employment terminated or permanent reassignment to another floor or facility), the Tenant Floor Warden shall advise the Emergency Director of the vacancy. This position will be activated during any emergency involving the relocation or evacuation of building occupants.

Deputy Tenant Floor Wardens (DTFW)

Deputy Tenant Floor Wardens are responsible for assisting the Tenant Floor Warden with the initiation of an evacuation of occupants via the Floor Searchers, should an evacuation or relocation be ordered by the Tenant Floor Warden. They will assume the role of Tenant Floor Warden in the Tenant Floor Warden's absence and will advise the Emergency Director if the Tenant Floor Warden is no longer able to perform the duties outlined in this manual (e.g., employment terminated or permanent reassignment to another floor or facility). They are also responsible for communicating with the Tenant Floor Warden on the status of the office space, the disposition of any persons requiring assistance to evacuate, and any missing occupants. Deputy Tenant Floor Wardens report directly to the Tenant Floor Warden. This position will be activated during any emergency involving the relocation or evacuation of building occupants.

Stair Monitors (SM)

Stair Monitors are responsible for the supervision of the occupants in an orderly evacuation of their office spaces into the stairwells should an evacuation or relocation be ordered by the Tenant Floor Warden. They are also responsible for monitoring the status of the stairwell, for advising evacuees where the appropriate assembly area is, for communicating with the Tenant Floor Warden on the status of the stairwell and for redirecting evacuees to an alternate stairwell if the integrity of their stairwell becomes compromised. Stair Monitors report directly to the Tenant Floor Warden. This position will be activated during any emergency involving the relocation or evacuation of building occupants.

Floor Searchers (FS)

Floor Searchers are responsible for the initiation and supervision of an orderly evacuation of occupants from their assigned office spaces to the Stair Monitors, should an evacuation or relocation be ordered by the Tenant Floor Warden. They are also responsible for communicating with the Tenant Floor Warden on the status of the office space, the disposition of any persons requiring assistance to evacuate, and any missing occupants. Floor Searchers report directly to the Tenant Floor Warden. This position will be activated during any emergency involving the relocation or evacuation of building occupants.

Assistance Monitors (AM)

Assistance Monitors are responsible for assisting persons requiring assistance to a safe area beside or within the stairwells to await assistance from the Building Response Team or the authorities, should an evacuation or relocation be ordered by the Tenant Floor Warden. They are also responsible for communicating with the Tenant Floor Warden on the status of the disposition of any persons requiring assistance to evacuate, and for providing that assistance should the emergency force an evacuation prior to assistance arriving. Assistance Monitors report directly to the Tenant Floor Warden. This position will be activated during any emergency involving the relocation or evacuation of persons requiring assistance to evacuate. If there is a new person requiring assistance in an Assistance Monitor's area of responsibility or if there is a change of status of a person requiring assistance to evacuate (e.g., a broken ankle heals), the Assistance Monitor will advise the Emergency Director so that the *Persons Requiring Assistance to Evacuate* list within the Facility Emergency Action Plan can be updated.

FIRE PROCEDURES

Tenant Floor Wardens – Fire Procedures

A) At the sound of a fire alarm, the Tenant Floor Wardens shall immediately:

- 1) Put on your identification, if readily available, and quickly check the integrity of the exits.
- 2) If the exits are safe, instruct the occupants to evacuate out of the building to the recommended assembly area **north of the building along 11th Street, between E and F Street.**
- 3) Do a quick check of the offices and washrooms. After the occupants have evacuated the floor instruct your Deputy and other assigned emergency staff to vacate the floor area.
- 4) Proceed via the nearest safe stairwell or exit to the recommended assembly area. Check in with the Assembly Area Coordinator and report on the status of your floor; then rejoin your group or relocate your group as directed by the Assembly Area Coordinator.

Note: For persons requiring assistance to evacuate, please refer to the Assistance Monitor procedures.

B) If you encounter fire or are informed of a fire on your floor:

- 1) Get everyone out of the room or area, activate the nearest manual pull station and close any doors behind you. This may help to control the fire by cutting off its oxygen supply, as well as limiting the spread of smoke to adjacent areas.
- 2) Assist the Deputy and Floor Searchers in evacuating the occupants of your floor out of the building to the recommended assembly area **north of the building along 11th Street, between E and F Street.**
- 3) Do a quick check of the offices and washrooms, and after the occupants have been evacuated, instruct your Deputy and other emergency staff to vacate the floor area.
- 4) Proceed via the nearest safe stairwell or exit to the recommended assembly area. Check in with the Assembly Area Coordinator and report on the status of your floor; then rejoin your group or relocate your group as directed by the Assembly Area Coordinator.

Note: If you ever have to open a closed door and you are suspicious that a fire condition may be present, feel the door first to see if it is hot. If it is hot to the touch, do not open that door.

C) Defend In Place:

In the event that the stairwells are inaccessible because of fire or smoke, follow these instructions:

- 1) Calmly get all the people into one area of the office building least affected by the fire.

- 2) Dial 911 on the nearest telephone and advise the Fire Department of your suite and floor number and location, if you are in immediate danger, and anything else that may assist the Fire Department to effect a rescue.
- 3) Close any doors leading into the room or area, and then take cloth, paper, strips of clothing, etc. and wedge them into the cracks around the door(s) (and wherever else smoke may enter the room).
- 4) Stand by for rescue by the Fire Department.

Note: The primary purpose of a fire extinguisher is to serve as an escape mechanism, in case a fire is blocking your only means of egress and knocking the fire down temporarily will aid the evacuation process. The fire extinguisher is not there to empower untrained individuals to become firefighters.

EVACUATION DRILL REPORT

To be completed by Tenant Floor Warden

Date: _____

Your Name: _____

Company: _____ Suite # _____

Building Name: _____

Building Address: _____

Floor(s) of Responsibility: _____

Time Bells Started: _____ Time Your Floor Cleared Building: _____

Time Reporting Floor Status: _____ Time Advised Safe to Return: _____

Reported to: __Senior Fire Official

__Building Incident Commander

__Assembly Area Coordinator

Y N N/A

- Was alarm clearly heard in all areas?
- Was announcement heard in all areas?
- Was announcement understandable?
- Were any doors wedged open or blocked?
- Were the hallways and exits clear of obstructions?
- Were any evacuation or suppression operations hindered?
- Did all occupants know where the assembly area was?
- Were everyone's duties understood?
- Is training/review required?
- Did occupants have a positive attitude towards the drill?
- Did occupants comply with the evacuation drill?

COMMENTS:

Deputy Tenant Floor Wardens – Evacuation Procedures (Single Tenant Floors)

At the sound of a fire alarm or upon being informed of an emergency or an evacuation order, the Deputy Tenant Floor Warden shall:

- 1) If the Tenant Floor Warden is not present on your floor, you shall assume the duties of the Tenant Floor Warden and assign someone to the position of Deputy Tenant Floor Warden.
- 2) Systematically check each area to ensure that Stair Monitors and Floor Searchers are evacuating the occupants of their areas, if an evacuation has been ordered. Take note of any persons requiring assistance to evacuate at the exits.
- 3) Report back to the Tenant Floor Warden, provide an evacuation status report, and then stand by for further instructions.

Stair Monitors – Evacuation Procedures (Single Tenant Floors)

At the sound of a fire alarm or upon being informed of an emergency or an evacuation order, Stair Monitors shall perform the following:

- 1) Proceed to your assigned exit stairwell and stand by to assist the occupants in their evacuation, if one has been ordered. Check the stairwell and confirm that it is unobstructed and clear of smoke.
- 2) As the floor's occupants report to you, instruct them to remove any footwear that may impede their movement in the stairwells (e.g., high heels).
- 3) Calmly evacuate the occupants through the stairwell, or reroute them around to another stairwell and evacuate them through that one, if so ordered.
- 4) As the occupants enter the stairwell, instruct them to keep against the wall and merge into the traffic flow (if any) as they descend or ascend to the next floor (similar to the merging lane of a freeway system).
- 5) Remind the occupants to evacuate outside; once they are outside the office building they are to proceed as directed by the Tenant Floor Warden and accumulate for a head count. Wait for further instructions from the Tenant Floor Warden.

Note: If there is any indication that the stairwell is contaminated or obstructed, contact your Tenant Floor Warden and direct your occupants to the other stairwell. If all stairs are contaminated, your Tenant Floor Warden may ask that you direct your occupants to a safe location on the floor to defend in place.

Floor Searchers – Evacuation Procedures (Single Tenant Floors)

At the sound of a fire alarm or upon being informed of an emergency or an evacuation order, Floor Searchers shall perform the following:

- 1) Put on your identification, if readily available.
- 2) If so directed by your Tenant Floor Warden, clear your area of occupants to the nearest safe exit or stairwell.
- 3) Do a quick check of your area for occupants lagging behind.
- 4) Report to the nearest safe stairwell, check in with the Stair Monitor and follow up at the back of your group as they evacuate through the stairwell, ensuring that they proceed to the recommended assembly area as directed by the Tenant Floor Warden.

Assistance Monitors – Evacuation Procedures

At the sound of a fire alarm or upon receiving an evacuation order within the office building, the Assistance Monitors shall perform the following:

- 1) Proceed to your designated person requiring assistance to evacuate and assist the individual to the exit.
- 2) If you are unable to locate your designated individual, report your findings to the Tenant Floor Warden.
- 3) Wait until other occupants from your floor and higher floors have descended down the stairwells, and then move your person requiring assistance onto the stairwell landing. If the person is mobile but slowed as a result of his or her condition, assist the person down the stairs and to at least two floors below the fire floor. If the person cannot negotiate the stairs (e.g., in a wheelchair), wait in the stairwell for assistance from the Fire Department or the Building Response Team. If it is dangerous to remain in the stairwells, defend in place as per instructions below.
- 4) Confirm that the Tenant Floor Warden has advised the Building Incident Commander and that assistance is on the way. If your floor becomes contaminated by heat or smoke, manually assist the person requiring assistance via the stairs to at least two floors below the fire floor.

Defend In Place:

In the event that the stairwells are inaccessible because of fire or smoke, follow these instructions:

- 1) Calmly get the persons requiring assistance into one area of the office building least affected by the fire.
- 2) Dial 911 on the nearest telephone and advise the Fire Department of your suite and floor number and location, if you are in immediate danger, and anything else that may assist the Fire Department to effect a rescue.
- 3) Close any doors leading into the room or area, and then take cloth, paper, strips of clothing, etc. and wedge them into the cracks around the door(s) (and wherever else smoke may enter the room).
- 4) Stand by for rescue by the Fire Department.

Instructions to Operate Fire Extinguishers

IMPORTANT The primary purpose of a fire extinguisher is to serve as an escape mechanism, in case a fire is blocking your only means of egress and knocking the fire down temporarily will aid the evacuation process.

The fire extinguisher is not there to empower untrained individuals to become firefighters. It is highly recommended that you take a hands-on fire extinguisher training program prior to using a fire extinguisher.

Prior to using a fire extinguisher, make sure the Fire Department is notified of the fire and ensure that you have your back to an exit. Fire extinguishers work only on small fires. Contact your emergency representative to set up fire extinguisher training.

Before Using a Fire Extinguisher:

- Activate the fire alarm to evacuate the building, and then call Error! Bookmark not defined.
- Ensure that you have an available evacuation route.
- Advise someone that you are going to try to use the fire extinguisher (Buddy System).
- Check that you are using the right fire extinguisher for the type of fire (**A** – Ordinary Solid Materials / **B** – Flammable Liquids / **C** – Electrical Fire / **D** – Combustible Metals).

If the fire is still small and not spreading,

ONLY THEN

Use the P.A.S.S. technique outlined below.

PULL Pull the pin. This will break the tamper seal.

AIM Aim low. Point the hose a few inches in front of the base of the fire. If you are right-handed, hold the extinguisher in your left hand and the end of the hose in your right. This will give you better control of the discharge path.

CAUTION: Do not touch the discharge horn of a CO₂ extinguisher as the CO₂ can damage your skin.

SQUEEZE Squeeze the handle to release the extinguishing agent.

SWEEP Sweep from side to side as you aim the discharge path from the bottom of the fire to the top and back again until the fire appears to be out, and then evacuate the area immediately.

NOTE You have approximately 10 seconds to knock the fire down once you begin to discharge the extinguishing agent. If you are unable to knock the fire down enough to allow you to evacuate, defend in place until help arrives.

NATURAL DISASTER PROCEDURES

Tenant Floor Wardens – Earthquake Procedures

In the event of an earthquake at 1001 Pennsylvania Avenue NW, Tenant Floor Wardens shall:

- 1) During the shaking, **DROP - COVER - HOLD**. Protect yourself by **dropping** to the floor and taking **cover** under a desk, sturdy table or other piece of furniture. **Hold** on to whatever you are under. If taking cover under a sturdy piece of furniture is not possible, get into a corner and facing out, bring your knees and hands up to protect yourself. Stay away (and face away) from windows (**do not stand in a doorway because you become a silhouette for a shrapnel hazard**). Stay away from anything that can shatter or fall on you. Count out loud (one-one thousand, two-one thousand, three-one thousand) to give yourself a time reference and to assure others around you that you are actively monitoring the situation. Encourage others to count with you so you know who is still safe and to give them something on which to focus.
- 2) Do not leave cover for at least 10 seconds after the shaking has stopped. Make sure it is not dangerous for you to come out from under cover (dangling light fixtures, broken glass, live electrical circuits in close proximity).
- 3) Cautiously leave your protection and begin to do an injury assessment. Try to plot your course around your floor space so that you are no more than a few steps from another safe spot (in case of an aftershock).
- 4) Announce to the floor occupants not to evacuate until the integrity of the stairwells and exits has been checked, and then dispatch Fire Control Teams with fire extinguishers to patrol the floor and extinguish small fires.
- 5) Do a complete check of your floor area, looking for injured or trapped persons, dangerous or shorting electrical circuits, damaged and leaking water lines, and unstable walls, ceilings, or furniture. Return telephone receivers to their cradles if they have fallen off. Reassure everyone and ask them to remain calm while you check for injuries. Barricade off unsafe areas.
- 6) Upon finding injured occupants, render first aid, if qualified. If not qualified, assist those rendering or requiring first aid.
- 7) Any individuals who are trapped in rooms, because of doors shifting in jambs or being blocked by debris, can be removed, if possible, by going through the drywall beside the door to extricate trapped occupants from the room. (Drywall is soft and can be broken through with a hammer or similar object.)
- 8) Check the integrity of the stairwells and exits on your floor and prepare to evacuate if so ordered. An evacuation of your space will be ordered only if the building safety systems have been compromised, the structural integrity of the building has been compromised or the building is on fire. Exterior evacuation of the building onto the street should be discouraged, as it is more dangerous outside the building following an earthquake than within it because of potential falling debris.
- 9) Implement sanitation procedures by placing garbage cans in the washrooms with triple plastic garbage can liners to be used as temporary toilets until the integrity of the sewage systems is checked. (This is to ensure that raw sewage does not pour into the floor spaces below you, should the sewer lines be damaged.)

- 10) Contact the Operations Section Chief or the Building Incident Commander at the Incident Command Post located **in the 1st Floor fire control room located on the north side of the southeast elevator core (across from elevator #9)** and advise of the status of your floor, and then follow the instructions of the Operations Section Chief or the Building Incident Commander.
- 11) If ordered to relocate, your recommended primary relocation assembly areas are on the lowest safe accessible floor(s) in the building, unless full building collapse (unlikely) is imminent or the building is experiencing an uncontrollable fire on the lower floors, in which case a full evacuation to a safe area outside will be required. The exterior evacuation is a last resort to be used only if all options to remain in the building have been exhausted. If an evacuation is absolutely necessary, please proceed to a safe area outside of the building. Do not stand near a building due to falling debris and do not stand near any potential hazards (e.g. power lines). Tenants must determine on their own where a safe area is located.
- 12) Report any missing persons to the Operations Section Chief or the Building Incident Commander.

Note: The building operations staff will be actively checking critical building systems following an earthquake and may not be immediately available to assist you with any problems you are experiencing as a result of the earthquake. It is important that you stabilize your floors and deal with spot fires and injuries as best you can and report any problems to building staff as soon as possible. Just be aware that it may be some time before building staff are in a position to assist you and that your corporate emergency action plan should reflect that.

Tenant Floor Wardens – Tornado Procedures

In the event of a Tornado Watch at 1001 Pennsylvania Avenue NW, Tenant Floor Wardens shall:

- 1) Put on your identification, if readily available.
- 2) If the WATCH has been upgraded to a WARNING, advise the occupants and reassure them.
- 3) Assist the occupants into the nearest safe stairwell and instruct them to sit on a stair and hold onto a railing. If they cannot get to a stairwell then, avoiding exterior walls and windows, they should take cover under sturdy furniture, holding onto whatever they are under. If no cover is available, they should crouch against a sturdy interior wall and facing out, bring their knees and hands up to protect themselves.
- 4) Do not leave cover until you are positive the tornado has passed and it is safe, or until instructed to do so by the Building Incident Commander.
- 5) Reassure everyone and ask them to remain calm while you check for injuries.
- 6) Do a complete check of your floor area, looking for injured or trapped persons, dangerous or shorting electrical circuits, damaged and leaking water lines, unstable walls, ceilings, or furniture. Return telephone receivers to their cradles if they have fallen off.
- 7) Upon finding injured occupants, render first aid, if qualified. If not qualified, assist those rendering or requiring first aid.
- 8) Barricade off unsafe areas.
- 9) Check the integrity of the stairwells and exits on your floor and prepare to evacuate if so ordered.
- 10) Implement sanitation procedures by placing garbage cans in the washrooms with triple plastic garbage can liners to be used as temporary toilets until the integrity of the sewage systems is checked. (This is to ensure that raw sewage does not pour into the floor spaces below you should the sewer lines be damaged.)
- 11) Contact the Operations Section Chief or the Building Incident Commander at the Incident Command Post located **in the 1st Floor fire control room located on the north side of the southeast elevator core (across from elevator #9)** via a firefighters' telephone and follow the instructions of the Operations Section Chief or the Building Incident Commander.
- 12) If ordered to evacuate your floor area to the exterior of the office building (due to structural failure), evacuate the occupants of your floor into the stairwells or exits and proceed to the designated recommended assembly area as directed by the Building Incident Commander. Do not run outdoors. Watch for falling debris and electrical wires when leaving the office building.
- 13) If fire occurs, activate the nearest fire alarm pull station (if it has not already been activated) and follow procedures outlined in the previous 'If you discover a fire' section.
- 14) Report any missing persons to the Operations Section Chief or the Building Incident Commander.

Note: The building operations staff will be actively checking critical building systems following a tornado impact and may not be immediately available to assist you with any problems you are experiencing as a result of the tornado. It is important that you stabilize your floors and deal with spot fires and injuries as best you can and report any problems to building staff as soon as possible. Just be aware that it may be some time before building staff are in a position to assist you and that your corporate emergency action plan should reflect that.

HUMAN INDUCED / TECHNOLOGY FAILURE PROCEDURES

Tenant Floor Wardens – Bomb Threat Procedures

Upon being informed of a code 'B' bomb threat at 1001 Pennsylvania Avenue NW, Tenant Floor Wardens shall:

- 1) Do not panic. Follow the directions of the Building Incident Commander.
- 2) Gather your Deputy and Monitors and check exits and evacuation routes for suspicious packages, prior to an evacuation taking place.
- 3) If you have been ordered to search your area for suspicious objects, coordinate a systematic search of your area, concentrating first on areas accessible to the general public (Red Zones). These areas will include corridors, elevator lobbies, public washrooms, under stairwells, within extinguisher cabinets, or within unlocked closets or utility rooms. When searching, systematically sweep the rooms in your area, starting with objects and furniture located waist-height to ground, then from waist to head, and then from head to ceiling.
- 4) If a suspicious package is found, **DO NOT DISTURB IT** in any way. Leave the area, leaving doors to the area open, and contact the Building Incident Commander via the nearest firefighters' telephone and follow instructions.
- 5) If ordered to evacuate the occupants from your floor, instruct the occupants to take their briefcases, lunch boxes, purses and small packages with them. This will decrease the number of packages to be examined by search teams, if a suspicious item has not already been found. Ensure that the doors to the area are left open to help vent the blast should the device activate.
- 6) Evacuate the occupants in your area to the nearest safe exit in the same manner as you would during a fire evacuation and send them to the recommended assembly area, which must be at least 450 yards away from the building. Ensure that the recommended assembly area is different from the assembly area used during the previous bomb threat.
- 7) Proceed to the Incident Command Post in the 1st Floor fire control room and advise the Building Incident Commander of the status of your designated area, any concerns and the extent of your search.
- 8) Proceed to the designated emergency assembly point as above, if it is safe to do so. Do not run outdoors.


Identifying a Possible Package Bomb

Package and letter bombs often have clues to alert recipients to possible trouble.

Things to look for are:

- Excessive weight for the size of the package or heavy at one end.
- Too much postage, usually in the form of stamps.
- No return address, or an unknown sender.
- Mailed from a foreign country, or via airmail or special delivery.
- A rigid or lopsided envelope.
- Common words are misspelled.
- Restrictive markings, such as confidential, urgent, personal or open by addressee only.
- Incorrect title for the addressee, or a title without a person's name.
- Handwritten or poorly typed address.
- Protruding wires, string or tinfoil.
- Excessive securing material, such as tape or string.
- Oily stains or discoloration on the outside of the package.

If you are suspicious: Don't touch the package, not even to move it out of the way.
IMMEDIATELY CALL 911 AND BUILDING SECURITY.



Tenant Floor Wardens – Suspicious Package Procedures

Upon being informed of the discovery of a suspicious package at 1001 Pennsylvania Avenue NW, Tenant Floor Wardens shall:

- 1) Do not panic. Follow the directions of the Building Incident Commander.
- 2) Gather your Deputy and Monitors and check to ensure that all exits and evacuation routes are clear, prior to an evacuation taking place.
- 3) If ordered to evacuate the occupants from your floor, instruct the occupants in your area to evacuate via the nearest safe exit in the same manner that you would during a fire evacuation and send them to the recommended assembly area, which must be at least 450 yards away from the building.
- 4) Proceed to the Incident Command Post in the 1st Floor fire control room and advise the Building Incident Commander of the status of your designated area and any concerns you may have. (For example, you discovered a second suspicious package on your floor during the evacuation.)
- 5) Proceed to the designated emergency assembly point as above, if it is safe to do so. Do not run outdoors.

Tenant Floor Wardens – Shelter-In-Place Procedures**Upon being advised to initiate Shelter-In-Place procedures:**

- 1) Put on your identification, if readily available.
- 2) If the exits are safe, instruct the occupants to relocate via the nearest safe stairwell to the shelter-in-place areas as follows:
 - Occupants on the Parking Levels, 1st Floor, 2nd Floor and 3rd Floor will proceed to the south side of the 4th Floor
 - Occupants on the 7th Floor, 8th Floor and 9th Floor will proceed to the south side of the 5th Floor
 - Occupants on the 10th Floor, 11th Floor, 12th Floor, 13th Floor and 14th Floor will proceed to the 6th Floor
- 3) Do a quick check of the offices and washrooms and, after the occupants have been relocated, instruct your Deputy and other emergency staff to vacate the floor area.
- 4) Proceed via the nearest safe stairwell to the shelter area. Check in with the Building Incident Commander and report on the status of your floor area. Rejoin your group and follow the instructions of the Building Incident Commander.
- 5) Enlist the aid of tenant volunteers to use duct tape and heavy gauge plastic to seal all cracks around passenger elevator doors serving the shelter floors as well as other doors leading into the area and washroom vents.

Note: The Tenant Floor Warden will advise the Building Incident Commander, via firefighter phones, if there are persons requiring assistance to relocate. The Assistance Monitors will assist their persons requiring assistance into the elevator brought to the floor by the Building Response Team and take them to the shelter-in-place areas.

Tenant Floor Wardens – Power Failure Procedures

In the event of a power failure at 1001 Pennsylvania Avenue NW, Tenant Floor Wardens shall:

- 1) Advise the occupants under your jurisdiction to stand by while the Building Incident Commander and Building Response Team assess the nature and duration of the power failure.
- 2) Ensure that everyone powers down their electrical equipment such as computers, photocopiers and other devices not on emergency power as a surge that is sometimes associated with power restoration may damage running equipment.
- 3) If an evacuation is ordered by the Building Incident Commander or your company management, advise able-bodied occupants to utilize the stairwells and persons requiring assistance to use the elevators (elevators are operated by the Building Response Team) to evacuate the building. If an evacuation is ordered by your company management only, notify Building Management or the Building Response Team - Security to advise them of your intentions.

If you are evacuating a person requiring assistance to evacuate, advise the Building Incident Commander that you require an elevator.

- 4) Advise those evacuating persons who are going to remove their cars from parking areas to take care as lower lighting conditions may make it harder to see pedestrians in parking areas and egress points. Also remind them that traffic lights may not be operational and their trip duration may be extended. Remind all occupants that should they come across an intersection where the traffic lights are not operational they are to use four-way stop procedures.
- 5) Once the floor is clear, ensure that management is securing the premises and then proceed to the Incident Command Post in the 1st Floor fire control room and advise that your floor space is clear and secured.
- 6) If you or your occupants have concerns about leaving the building, advise the Building Incident Commander and proceed to an area as directed by the Building Incident Commander while he or she determines the best course of action.

Tenant Floor Wardens – Personal Violence Procedures

Active Shooter

If you are notified of an active shooter in the building or are notified of a LOCK DOWN:

If you are not aware of the exact location of the shooter or cannot safely escape:

- 1) Direct occupants to move to the nearest room or office and go with them.
- 2) Ensure that doors are closed and locked and lights are turned off if possible. Direct occupants to silence any cell phones or electronic devices. Barricade the door if possible.
- 3) Get low behind furniture, keep quiet and act as if no one is in the room.
- 4) DO NOT answer the door.
- 5) Follow the **9-1-1 Protocol**.
- 6) As an absolute last resort and only if your life is immediately threatened, attempt to incapacitate the shooter. Coordinate with those around you, act aggressively, throw or use improvised weapons to catch the shooter by surprise.
- 7) Wait for the police to assist you out of the building.

How to react when law enforcement arrives:

- Remain calm, and follow officers' instructions.
- Put down any items in your hands (e.g., bags, jackets).
- Immediately raise hands and spread fingers.
- Keep hands visible at all times.
- Avoid making quick movements toward officers such as holding on to them for safety.
- Avoid pointing, screaming and/or yelling.
- Do not stop to ask officers for help or direction when evacuating, just proceed in the direction from which officers are entering the premises.

If you are aware of the exact location of the shooter and you are confident you can safely escape:

- 1) Gather occupants in your area and exit the building as quickly as you safely can (a fast-moving target is harder to hit than a slow-moving or stationary target).
- 2) Notify anyone you may encounter to exit the building immediately.
- 3) Flee to a safe location, in a nearby building or at a safe distance away from the building.
- 4) If you enter a nearby building:
 - Proceed to a securable room and advise anyone you may encounter of the incident.

- Turn off the lights if possible and silence any cell phones or electronic devices.
 - Get low behind furniture, keep quiet and act as if no one is in the room.
 - DO NOT answer the door.
 - Wait for the police to assist you out of the building.
- 5) Follow the **9-1-1 Protocol**.
 - 6) Give the operator all requested information.

Information to provide to law enforcement or 911 operator:

- Location of the active shooter
- Number of shooters, if more than one
- Physical description of shooter/s
- Number and type of weapons held by the shooter/s
- Number of potential victims at the location

Note: Elevators are locked out in order to restrict the movement of the active shooter. Exterior entrance doors are locked to ensure no one enters the building while an active shooter event is taking place.

Note: "Active shooter" is a phrase coined by law enforcement that describes an armed person who has used deadly physical force on persons and continues to do so while having unrestricted access to additional victims.

Unarmed Violent Intruder

In the event of a situation involving an unarmed violent intruder:

- 1) Instruct occupants to retreat to a safe place (hide) and stay under cover; do so as well.
- 2) If time and safety permit, follow the **9-1-1 Protocol**.
- 3) Stay in place and if safety permits warn all others in the area of the situation.
- 4) Listen for announcements.
- 5) Remain hidden until police arrive. Follow their instructions.

FIRST AID PROCEDURES

Emergency First Aid

The following instructions deal with only the most likely injuries to occur after a disaster. The following does not include every type of injury, nor is it intended to substitute for a qualified first aid person.

1. THE ABCs OF RESUSCITATION

A) Airway (do not move neck if you suspect a neck injury):

1. Place a hand on the victim's forehead to tilt head back and use fingers of the other hand under the chin to lift jaw.

B) Breathing (artificial respiration):

1. With ear by victim's mouth, look for chest movement.
2. Listen for breathing.
3. Feel breath on your cheek.
4. If victim not breathing, start artificial respiration immediately:
 - a) Keep head back.
 - b) Pinch victim's nostrils.
 - c) Position your mouth over victim's mouth.
 - d) Give 2 full (stacked) breaths.
 - e) Continue to give 1 breath every 5 seconds until victim breathes normally, or help arrives.
5. If when attempting artificial respiration and air does not enter the victim's chest:
 - a) Reposition victim's head and attempt artificial respiration again.
 - b) If successful, implement Section C (Circulation).
 - c) To clear the victim's airway place the heel of one hand on top of the heel of the other hand, just above the naval, but well below the tip of the breast bone. With 6 to 10 quick thrusts, press upwards into the upper abdomen.
 - d) If this attempt fails, open the victim's mouth by grasping tongue and lower jaw between thumb and fingers, then lift chin. Insert the index finger of your other hand deep into the victim's mouth and use finger sweep to dislodge and remove foreign body.
 - e) Attempt to ventilate once again.
 - f) If unsuccessful, repeat the above sequence of abdominal thrusts and finger sweeps with attempted ventilation until the obstruction is cleared.

C) Circulation (C.P.R.):

1. Feel neck for pulse (in the small of the neck).
2. If you feel a neck pulse, then continue the ventilations.
3. If neck pulse is not felt, do C.P.R. as follows:
 - a) Place the heel of your hand on the breastbone above its lower tip, between the victim's nipples. Place the heel of your other hand on your first hand.
 - b) Press straight down to compress the chest 1-1/2" to 2", 100 times per minute. Give 2 ventilations after every 30 compressions. Continue until qualified help arrives and you are relieved.

2. BLEEDING

Serious bleeding occurs with severed blood vessels and deep cuts.

A) Apply Direct Pressure to the Wound:

1. Remove clothing around the wound to expose the wound.
2. Cover the wound with sterile clean cloth.
3. Apply firm pressure directly over the wound with your hand. Use your bare hand if no dressing is available.

B) Continue Pressure Until Bleeding Stops:

(This may take 15 to 20 minutes)

1. Assist the victim to lie down.
2. Elevate bleeding extremity, unless the bone is broken.
3. When bleeding stops, apply a further dressing on top of the original dressing and bandage firmly.
4. Should blood soak through the initial dressings, apply additional dressings and bandage more firmly.

C) Broken Bone, Objects or Glass Protruding Through Skin:

1. Do not remove imbedded objects from the wound(s).
2. Apply pressure close to the wound, without pressing on the object or broken bone.
3. Place sterile dressing around the wound and cover.
4. Maintain pressure and prevent movement of the object by bandaging bulky pads in place around the object.

3. EYE INJURIES**A) Puncture Wounds:**

1. Puncture wounds are serious and require immediate medical attention.
2. Cover both eyes lightly and bandage.

B) Foreign Body in the Eye:

1. Do not try to remove imbedded foreign bodies (never rub the eye).
2. Cover both eyes lightly with bandages.

C) Chemicals in the Eye:

1. Wash the eye immediately with large amounts of cold running water for at least 15 minutes or longer, if the situation requires it.

4. SEVERE BURNS AND SCALDS:

1. Cool the burnt area with cold water to relieve pain.
2. Remove rings and bracelets from the affected area before the part starts to swell.
3. Cover the area with a clean cloth and secure lightly with bandages.
4. For burns and scalds with areas larger than a quarter, ensure the victim receives hospital treatment.
5. Never touch, breathe on, or cough on a burn.
6. Leave blisters alone.
7. Never remove clothing on or around a burn.
8. Never apply medications, ointments or greasy substances to a burn area.

5. BONE AND JOINT INJURIES:

1. Ensure that the victim's breathing is normal.
2. Control bleeding around a protruding bone by applying pressure close to the wound but not pressing directly upon the broken bone.
3. Suspect that the bone is broken if the injured limb is painful, swollen, or shows deformity.
4. When in doubt, treat joint and bone injuries as broken:
 - a) Immobilize the injured area:
 - i) Place pillows, sand bags or clothing on both sides of the injured limb, or hold it with your hands to keep it in position.
 - ii) For neck or back injuries, keep the victim still, supporting head and neck, until help arrives.
5. Relieve pain by applying cold (not heat) to the injured bones and joints.

6. HEART ATTACK:**A) Heart Attack Warning Signals May Include the Following:**

1. The feeling of squeezing pain or heavy pressure in the chest, jaws, or arms.
2. Shortness of breath, sweating, pale skin and weakness.
3. Vomiting or nausea.
4. Abdominal discomfort (with belching or indigestion).
5. Anxiety, apprehension, or fright.
6. The denial that the victim is experiencing a heart attack.

B) Action to be Taken When You Suspect a Heart Attack:

1. Help the victim to rest in a semi-sitting position.
2. If the victim requires medication for his condition, then assist the victim in taking it.
3. Ensure prompt medical attention, then reassure the victim that help is on the way.
4. Loosen belts, collars, or other tight clothing.
5. Keep the victim quiet.

7. STROKE:**A) Stroke Warning Signals May Include the Following:**

1. Sudden numbness or weakness of the face, arm or leg, especially on one side of the body.
2. Sudden confusion, trouble speaking or understanding.
3. Sudden trouble seeing in one or both eyes.
4. Sudden trouble walking, dizziness, loss of balance or coordination.
5. Sudden, severe headache with no known cause.

B) Action to be Taken When You Suspect a Stroke:

1. Ask the individual to smile.
2. Ask him or her to raise both arms.
3. Ask the person to speak a simple sentence.
4. If he or she has trouble with any of these tasks, call 911 immediately and describe the symptoms to the dispatcher.


PERSONS REQUIRING ASSISTANCE

In the event that a person requires assistance to evacuate, the Tenant Floor Wardens will be responsible for ensuring that assistance is provided by pre-assigned Assistance Monitors, or by assigning floor occupants to that individual should Assistance Monitors not be present. In most cases, the individual will have some means by which his or her evacuation may be facilitated. However, if that means becomes unavailable, or if the individual's condition is due to injury caused either directly or indirectly by the fire condition, occupants may have to manually assist the person to the nearest safe exit. The following are examples of some techniques that may be used to transport a person requiring assistance to the exits.

Two-Person Carries

(1) Interlocking Wrist Carry

- a) Facing your fellow rescuer, grab your right wrist with your left hand.



- b) Grab your fellow rescuer's free wrist, forming a seat.



- c) Both rescuers slide the seat between the back of the chair and the person's back and under his or her buttocks.



- d) Both rescuers then lift simultaneously and carry the person to safety.



(2) **The Chair Lift**

- a) Lay the person on his or her back and slide a chair under his or her buttocks, until the person is in a sitting position but still lying on the floor.



- b) Put the person's hands on his or her lap, and slowly raise the chair to a vertical position.



- c) Rescuers may then pick up the chair (either side-by-side, or front and back) and proceed to safety.



(3) Gravity Assist Method (Heavy Persons)

- a) Assist the person requiring assistance to a sitting position at the top of the stair.
- b) One rescuer gets below the person and holds the person's legs off the stair while the other rescuer reaches under the person's arms.
- c) Both rescuers then lower the person one step at a time until the person is safe.



FACILITY DESCRIPTION

General Description of the Office Building

1001 Pennsylvania Avenue NW is a 14-story office building constructed in 1986 / 1987 and is currently managed by Hines.

The office building is located at 1001 Pennsylvania Avenue NW, on the city block bounded by 10th Street NW to the east, Pennsylvania Avenue NW to the south, 11th Street NW to the west and E Street NW to the north.

This building is made up of a north and a south tower joined together.

There are a number of security cameras located in the building, with the security office being located at the southwest corner of the loading dock. All entrances to the building except for the main 11th Street NW and the Pennsylvania Avenue address entrance require card access during business hours.

This building is located to the west (across 10th Street NW) of the J Edgar Hoover FBI Building.

The two parking entrances are closed and secured during non-business hours.

The building has a designated Incident Command Post located **in the 1st Floor fire control room**, from which a building response to an emergency may be coordinated by the Building Incident Commander, provided that area is still safe.

Fire Alarm System

The office building has a supervised fire alarm system with integrated emergency voice paging system.

Upon alarm activation, a continuous general alarm will sound on the floor of activation, the floor above and the floor below along with any floors connected to those three floors via interconnecting tenant stairwells. An exterior alarm bell on the 10th Street side of the building will also sound. No other alarm will sound in the building. A secondary activation will automatically result in a full general alarm sounding throughout the building. If a fire condition is confirmed the alarm system can be placed into full general alarm. Automated voice announcements will also be heard on alarm floors via the automated emergency voice paging system.

Exit System

There are four above-grade exit stairwells. Each stairwell has its own code to identify it from another so that a reference may be made in the event that one stairwell is contaminated by smoke and is unusable. The stairs exit the building as follows:

- Stair NE: Exits onto the sidewalk of 10th Street NW
- Stair SE: Exits onto the sidewalk of 10th Street NW
- Stair SW: Exits into the 1st Floor south main lobby
- Stair NW: Exits into the 1st Floor north main lobby

Floors are numbered inside the stairwells. Each exit door is clearly marked by an exit sign above the doorway.

Upon alarm activation, all exit stairwell doors, which are kept locked for security purposes, will unlock.

The **fire doors within some tenant spaces**, which are normally kept open for occupant convenience, close automatically upon activation of the fire alarm system to keep smoke and fire from spreading to adjacent areas.

Recommended occupant assembly areas for different emergency events are as follows:

Fire:	West of the building on the east sidewalk of 12th Street NW between Pennsylvania Avenue NW and E Street NW
Earthquake / Tornado:	On the lowest safe floors of the building, unless full evacuation is required, then to the exterior of the building as directed by the Building Incident Commander in consultation with the Building Response Team members upon conducting exterior reconnaissance
Bomb threat:	Dependent on whether a device was found, how large it is and where it is located
Internal hazmat incident:	Upwind
Civil disturbance:	On the occupant's floor

External hazmat incident / shelter-in-place areas are as follows:

- Occupants on the Parking Levels, 1st Floor, 2nd Floor and 3rd Floor will proceed to the south side of the 4th Floor
- Occupants on the 7th Floor, 8th Floor and 9th Floor will proceed to the south side of the 5th Floor
- Occupants on the 10th Floor, 11th Floor, 12th Floor, 13th Floor and 14th Floor will proceed to the 6th Floor

There are three below grade exit stairs. These stairs exit as follows:

- NE Below Grade Stair: Exits into the 1st Floor North lobby
- Center Below Grade Stair: Exits into the 1st Floor 10th Street NW entrance lobby.
- SE Below Grade Stair: Exits onto the sidewalk along 10th Street NW

Communications

Emergency Voice Paging System

There is an emergency voice paging system contained within the office building that is capable of addressing all areas of the office building.

Fire alarm related announcements are automated and will sound via digital recordings after alarm activation.

Firefighters' Telephone

There are **multiple** firefighters' telephones per floor. Firefighters' telephones are located **in all stairwells on each floor**. The fire phones provide two-way communications and are for the use of the Fire Department and office building supervisory staff.

In addition to the stairwell firefighters' telephones there are firefighters' telephone jacks located in each passenger and freight elevator lobby. The associated portable phones are in the Fire Control Center.

Emergency Power

In the event of a power failure, emergency power is provided by **two** generators. The emergency generators are activated automatically upon a power failure.

Elevators

The office building has **twenty-seven** elevators to serve its occupants.

The elevator cars descend automatically upon alarm activation to **the 1st Floor**, where they are locked out until either the fire alarm system is reset (elevators need to be manually reset after fire alarm system is reset), or the automatic grounding is bypassed by a special Fire Department key.

In the event that the fire alarm was initiated on the 1st Floor, the elevators are programmed to recall to **the 2nd Floor (high-rise elevators) and the 3rd Floor (low-rise elevators)** as an alternate destination, so those within the elevators at the time of an alarm are not brought to the fire floor.

Fire Equipment

Sprinklers

Wet sprinklers have been installed to provide automatic fire suppression within **entire building except parking levels and loading dock**. Dry sprinklers are used in **parking levels and loading dock** to ensure that the sprinklers will function in cold weather.

Fire Extinguishers

There are **multiple 5 lb. ABC dry chemical** fire extinguishers per floor. The extinguishers have labels with instructions describing how to operate them, their age, serial number and the type of fire against which they can be used.

NOTES

NOTES

1001 PENNSYLVANIA AVENUE NW

WASHINGTON, DISTRICT OF COLUMBIA

FIRE EVACUATION PLAN

